

# PR-C – Counting Scale

## Changing Unit Weight.

1. Make sure the scale is turned off first.
2. Press and hold the UWS key and turn on the scale. Each display will show a single 0 in it.
3. Press 0 key to enter U Set (User settings). In the Weight display window it will show the current user settings (default 2211).



**The first digit (2)** = Anti-Shudder function. 0~5 The higher the anti-shudder function, the higher the resistance strength against vibration (default = 2).

**The second digit (2)** = Zero range setting: 0 = +/- 0d more, 1 = +/- 1d more, 2 = +/- 2d more, 3 = +/- 3d more.

**The third digit (1)** = Auto zero range setting: 0 = +/- 0d, 1 = +/- 1d below, 2 = +/- 2d below.

**The fourth digit (1)** = Unit setting: 0= g, 1= kg, 2= lb, 3= oz.

4. **To switch from kg to grams** - In the Unit Weight display window, enter the desired settings (eg. for grams 2210) and press SAMPLE to enter and return to normal weighing mode.

